

Adventure Dome and Tunnel

Owner's Manual

MODEL # CRA10-040 / Adventure Dome and Tunnel Dome: 4ft. x 4ft. x 36in. / 121cm x 121cm x 91.4cm Tunnel: 20in Diameter x 40in length / 51cm x 102cm



DESCRIPTION	QTY.
DOME TENT 100% Polyester	1
POLES Fiberglass Pole; Black	2
STAKES Metal	4
TUNNELS 100% Polyester	1
CARRY POUCH 100% Polyester	1

ASSEMBLY INSTRUCTIONS

STEP 1:

Confirm product contents by emptying contents of bag(s) and confirming all parts are included and undamaged.

STEP 2:

Select a smooth level site and spread out your tent.


STEP 3:

Extend poles and place in position ready for installation. Take a tent pole and push it through a pole sleeve located at the top of tent. Repeat process with the remaining tent pole. Poles will cross each other at the center.


STEP 4:

After sliding poles through sleeves, gently flex poles into an arch and insert ends into pole pockets at base of tent.

NOTE: Make sure pole sleeve fabric is evenly distributed along pole and does not catch at pole joints. Undue stress could break pole or tear fabric.



Connect tunnel to tent by securing toggles on tent to loops on tunnel.



*CAUTION:

Tunnel pops open. Take caution when handling.

For questions, concerns or replacement parts call Gigatent at our Toll Free Number: 877-836-8701 Monday-Thursday 9am-5pm EST, Friday 9am-12pm EST or email us at customerservice@gigatent.com

WASHING & CARE INFORMATION

Hand wash using a mild dishwashing soap and soft sponge, then allow the fabric to completely air dry. I prevent mold or mildew do not store wet or damp.

NEVER LEAVE CHILDREN UNATTENDED. AGES 3 AND UP RECOMMENDED.





CAUTION:

This product was not designed to be left out in the sunlight for extended periods of time. Prolonged UV exposure will rapidly break down the fabric of this product. UV damage is not covered under our warranty.

WARNING:

Keep all flame and heat away from tent and tent fabric. This tent meets flammability requirements of CPIA -84 THIS TENT IS NOT FIRE PROOF. IF LEFT IN OPEN FLAME THE TENT WILL BURN.

CAUTION:

Never use any fuel-burning or oxygen-consuming devices, or any devices that produce fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This can result in carbon monoxide poisoning, injury or death.

Contents and colors may vary. Please retain package for future reference.

TO VIEW FULL SELECTION OF OUR PLAY TENT PRODUCT LINE, GO TO WWW. GIGATENT.COM

QUALITY GUARANTEE

QUALLIT SUBHANTEE
Gigatent guarantees the quality of this
Crayola product. If this product does not
perform properly, please contact us.
1-877-836-8701
U.S.A, Canada and other countries:
customerservice@gigatenet.com

QUALITE GARANTIE

QUALITE GARANTIE
Gigatent garantit la qualite de les produit
Crayola. En cas de defectuosite,
commniquez avec nous au
1-877-836-8701
E.U., Canada & autres pays:
customerservice@gigatenet.com

CALIDAD GARANTIZADA

Gigatent garantiza la calidad de este producto Crayola. Si este producto no funciona adecuadamente, sirvase contactarnos al 1-877-836-8701 EE.UU., Canada & otros paises: customerservice@gigatenet.com

gigatent

© 2011 Cravola

Manufactured in China for 55 Haul Rd Wayne, New Jersey 07470 www.gigatent.com

www.crayola.com Official Licensed Product Produit Sous Licence Officielle Producto Bajo Licencia Oficial

ABOUT US

Oval Logo Design™, Chevron Design™, Crayola™ and Serpentine Design™ are trademarks of Crayola used under license

A Hallmark Company

STYLE #: CRA10-040



Manufacturer's Warranty

Warranty covers product to be free from defects in material and workmanship for 14 days after date of purchase.

Warranty does not cover natural breakdown of materials that occur inevitably with extended use (e.g., UV damage, exhausted zippers, defects caused by accident, abuse, alteration, animal attack, storm damage, misuse or improper care.

This product is covered for 14 days from date of purchase. Please check all contents to verify product has no missing or broken parts. Gigatent will mail replacement parts free of charge within the 14 Day Manufacturer's Warranty by calling 1-877-836-8701 or emailing customerservice@gigatent.com. We highly recommend logging on to our website at www.gigatent.com should you need customer service. Any parts in need of replacement after the 14 Day Manufacturer's Warranty can be purchased for a reasonable charge, plus shipping and handling. We require that products accepted for any repair must be properly cleaned according to our care instructions.

WARNING:

This product was not designed to be left out in the sunlight for extended periods of time. Prolonged UV exposure will rapidly break down the fabric of this product. UV damage is not covered under our warranty.

WARNING : NEVER LEAVE CHILDREN UNATTENDED.
AGES 3 AND UP RECOMMENDED.

Play tent for indoor and outdoor use.

Keep all Flame and Heat away from tent and tent fabric. This tent meets flammability requirements of CPAI-84.

THIS TENT IS NOT FIRE PROOF.

IF LEFT IN OPEN FLAME THE TENT WILL BURN.

CAUTION: Never use any fuel-burning or oxygen-consuming devices, or any devices that produce fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This can result in carbon monoxide poisoning, injury or death.

MADE IN CHINA.