

MODEL # CT147/ Teepee

Teepee Dimensions 40" x 40" x 46"




DESCRIPTION	QTY.
TEPEE	
100% Polyester	1 ____
POLES	
Fiberglass Pole	8 ____
CARRY POUCH	
100% Polyester	1 ____

ASSEMBLY INSTRUCTIONS

TEEPEE SET UP

- 1) Assemble all poles.
- 2) Slide each of the 4 shorter poles through the floor pole sleeves. **(Figure A)**.
- 3) Attach the 4 corner hubs to connect the floor poles. NOTE: arrows are embossed on the portion of hubs that connect to the floor poles. **(Figure B)**.
- 4) Slide each of the wall poles through the pole sleeves starting at the top of the teepee. Connect the bottom of the poles to each of the remaining portion of the hubs. **(Figure C)**.





Manufacturer's Warranty

Warranty covers product to be free from defects in material and workmanship for 14 days after date of purchase.

Warranty does not cover natural breakdown of materials that occur inevitably with extended use (e.g., UV damage, exhausted zippers, defects caused by accident, abuse, alteration, animal attack, storm damage, misuse or improper care.

This product is covered for 14 days from date of purchase. Please check all contents to verify product has no missing or broken parts. Gigatent will mail replacement parts free of charge within the 14 Day Manufacturer's Warranty by calling 1-877-836-8701 or emailing customerservice@gigatent.com. We highly recommend logging on to our website at www.gigatent.com should you need customer service. Any parts in need of replacement after the 14 Day Manufacturer's Warranty can be purchased for a reasonable charge, plus shipping and handling. We require that products accepted for any repair must be properly cleaned according to our care instructions.

WARNING:

This product was not designed to be left out in the sunlight for extended periods of time. Prolonged UV exposure will rapidly break down the fabric of this product. UV damage is not covered under our warranty.

WARNING : NEVER LEAVE CHILDREN UNATTENDED.

AGES 3 AND UP RECOMMENDED.

Play tent for indoor and outdoor use.

Keep all Flame and Heat away from tent and tent fabric.

This tent meets flammability requirements of CPAI-84.

THIS TENT IS NOT FIRE PROOF.

IF LEFT IN OPEN FLAME THE TENT WILL BURN.

CAUTION: Never use any fuel-burning or oxygen-consuming devices, or any devices that produce fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This can result in carbon monoxide poisoning, injury or death.

MADE IN CHINA.

For questions or concerns call Gigatent at our Toll Free Number: 877-836-8701
Monday-Thursday 9am-5pm EST, Friday 9am-12pm EST or email us at customerservice@gigatent.com
For replacement parts login to gigatent.com/replacements

WARNING :
NEVER LEAVE CHILDREN UNATTENDED.
WINDY CONDITIONS MAY UPROOT THE TENT.
ALWAYS STAKE DOWN TENT. ADULT
SUPERVISION REQUIRED.
AGES 3 AND UP RECOMMENDED.

WARNING:
Keep all flame and heat away from tent and tent fabric.
This tent meets flammability requirements of CPAI-84.
THIS TENT IS NOT FIRE PROOF.
IF LEFT IN OPEN FLAME THE TENT WILL BURN.

NOTE:
This tent meets the state of
California's requirement of
Prop-65.

WARNING:
Never use any fuel-burning or oxygen-consuming
devices, or any devices that produce fumes, including
stoves, lanterns, candles, hibachis or heaters in or
around your tent. This can result in carbon monoxide
poisoning, injury or death

CAUTION:
This product was not designed to be left out in the
sunlight for extended periods of time. Prolonged UV
exposure will rapidly break down the fabric of this
product. UV damage is not covered under our warranty.

WASHING & CARE INFORMATION
Hand wash using a mild dishwashing soap and soft
sponge, then allow the fabric to completely air dry.
To prevent mold or mildew do not store wet or damp.


Manufactured in China for
Gigatent
55 Haul Rd
Wayne, New Jersey 07470
www.gigatent.com
1-877-836-8701

TO VIEW FULL SELECTION OF OUR
PLAY TENT PRODUCT LINE,
GO TO WWW.GIGATENT.COM

STYLE #:CT147

Contents and colors may vary. Please retain package
or future reference.